

CALIBRATION INSTRUCTION



CALIBRATION OPERATION

After the connection of device follow the instruction for calibration:

- 1) Completely lower the 2 flaps (maximum sensor voltage).
- 2) Press the **FS** button on the back of the touch panel for at least 5 seconds (to confirm the setting you will see 2 led central turn on).
- 3) Completely raise the 2 flaps (mimum sensor voltage).
- 4) Press the **IS** button on the back of touch panel for at least 5 seconds (to confirm the setting you will see 2 led central turn on).